Safety information

Please read this important safety information before you use the device. It contains general safety information for devices and may include content that does not apply to your device. Follow the warning and caution information to prevent injury to yourself or others and to prevent damage to your device.

The term 'device' refers to the product, the items supplied with the product, and any approved accessories used with the product.

The services and features provided with this device are intended for users aged 18 and above.

Warning

Failure to comply with safety warnings and regulations can cause serious injury or death

Your device contains magnets. Keep them at least 15 cm away from implanted medical devices, such as pacemakers or insulin pumps, that may be affected by magnets. Stop using your device if you suspect any interference with your medical device and consult your physician or your medical device manufacturer

Do not use damaged power cords or plugs, or loose electrical sockets

Unsecured connections can cause electric shock or fire.

Do not touch the device, power cords, plugs, or the electric socket with wet hands or other wet body parts

Doing so may cause electric shock.

Do not pull the power cord excessively when disconnecting it

Doing so may cause electric shock or fire.

Do not bend or damage the power cord

Doing so may cause electric shock or fire.

Do not use the device with wet hands while the device is charging

Doing so may cause electric shock.

Do not directly connect together the charger's positive and negative terminals

Doing so may cause fire or serious injury.

Do not use your device outdoor during a thunderstorm

Doing so may result in electric shock or device malfunction.

Use of genuine accessories and parts provided by the official distributor (IICOMBINED Co., Ltd.) or approved by the manufacturer (Samsung Electronics Co., Ltd.) is recommended. Lenses installed by users, such as prescription lenses, are not covered

- Using non-approved chargers, cables, and accessories may shorten the life of your device or cause the device to malfunction and may cause serious injuries or damage to your device. They may also cause a fire or cause the battery to explode.
- The manufacturer cannot be responsible for the user's safety when using accessories or supplies that are not manufactured or supplied by the manufacturer.

Do not carry your device in your back pockets or on your waist

- The device may be damaged, explode, or result in a fire if too much pressure is applied to it.
- You may be injured if you are bumped into or fall.

Do not place the device in checked baggage

The device contains a Lithium Ion (Li-Ion) battery and may pose a risk of fire or overheating if damaged by impact, pressure, or similar conditions.

Do not drop or cause excessive impact to the device

- This may damage your device or battery, cause the device to malfunction, or shorten its lifespan.
- This may also cause overheating, combustion, fire, or other hazards.

Handle and dispose of the device and charger with care

- Never dispose of the device in a fire. Never place the device on or in heating devices, such as microwave ovens, stoves, or radiators. The device may explode when overheated. Follow all local regulations when disposing of used devices.
- Never crush or puncture the device.
- Avoid exposing the device to high external pressure, which can lead to an internal short circuit and overheating.

Protect the device and charger from damage

- Avoid exposing your device to very cold or very hot temperatures.
- Extreme temperatures can damage the device and reduce the charging capacity and life of your device and battery.
- Do not use a cable whose covering is peeled off or damaged, and do not use any charger that is damaged or malfunctioning.
- Do not turn on or use the device when the battery compartment is exposed.

Do not store your device near or in heaters, microwaves, hot cooking equipment, or high pressure containers

- The battery may leak.
- Your device may overheat and cause a fire.

Do not heat or bend the device

Do not apply heat or modify the device to adjust the fit. Doing so may cause damage to the device or fire.

Do not use or store your device in areas with high concentrations of dust or airborne materials

Dust or foreign materials can cause your device to malfunction and may result in fire or electric shock.

Prevent the charger port and charging contacts from contact with conductive materials, such as liquids, dust, metal powders, and pencil leads. Do not touch the multipurpose jack with sharp tools or cause an impact to the multipurpose jack

Conductive materials may cause a short circuit or corrosion of the terminals, which may result in an explosion or fire.

Do not bite or suck the device

- Doing so may damage the device or result in an explosion or fire.
- Children or animals can choke on small parts.

Do not insert the device or supplied accessories into the eyes, ears, or mouth

Doing so may cause suffocation or serious injuries.

Do not handle a damaged or leaking Lithium Ion (Li-Ion) battery

- If the battery fluid comes into contact with your skin or eyes, rinse immediately with water and seek treatment from a medical professional.
- For safe disposal of your Li-Ion battery, contact the official distributor.

Do not share the device with people who have infectious diseases or illnesses or the symptoms of such diseases or illnesses on their eyes or skin

There is a risk of infection with infectious diseases or illnesses, such as conjunctivitis.

Do not use the device when your attention may be distracted to prevent accidents

- Take off the device when operating machinery or tools, working at heights, using open flames, or performing other tasks that may affect your safety.
- If you cannot take off the device, turn off the device or lower the volume before using it.

Do not rely on AI features to detect or prevent emergencies, accidents, or other urgent situations

- AI features are not designed or intended for use in situations where death, injury, or property damage may occur. If you require information or guidance regarding emergencies, consult relevant authorities, such as the police, fire department, or medical institutions.
- Emergency calls cannot be placed with this device. Use of a mobile device to make an emergency call is recommended.



Caution

Failure to comply with safety cautions and regulations can cause injury or property damage

Do not use your device near other electronic devices

- Most electronic devices use radio frequency signals. Your device may interfere with other electronic devices.
- This may cause interference with other devices, such as audio equipment and telephones.

Do not use your device in environments where radio frequency interference may occur

- Avoid using your device within a 15 cm range of a pacemaker, if possible, as your device can interfere with the pacemaker.
- If you use medical equipment, contact the equipment manufacturer before using your device to determine whether or not the equipment will be affected by radio frequencies emitted by the device.
- On an aircraft, using electronic devices can interfere with the aircraft's electronic navigational instruments. Follow the regulations provided by the airline and the instructions of aircraft personnel.
- Turn off the device in hospitals and follow hospital regulations. Radio waves emitted by the device may affect medical devices.
- Do not turn on the device if you notice any interference with your medical device.
- Electronic devices in your car may malfunction, because of radio interference from your device. Contact the manufacturer for more information.

Do not expose the device to heavy smoke or fumes

Doing so may damage the outside of the device or cause it to malfunction.

If you use a hearing aid, contact the manufacturer for information about radio interference

The radio frequency emitted by your device may interfere with some hearing aids. Before using your device, contact the manufacturer to determine whether or not your hearing aid will be affected by radio frequencies emitted by the device.

Do not use your device near devices or apparatuses that emit radio frequencies, such as sound systems or radio towers

Radio frequencies may cause your device to malfunction.

Turn off the device in potentially explosive environments

- Always comply with regulations, instructions and signs in potentially explosive environments.
- Do not use your device at refuelling points (petrol stations), near fuels or chemicals, or in blasting areas.
- Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or accessories.

If any part of the device is broken, smokes, or emits a burning odor, stop using the device immediately. Use the device again only after it has been repaired at the official distributor

- Broken device could cause injury to your hands and face.
- When the device smokes or emits a burning odor, it may result in battery explosion or fire.

Comply with all safety warnings and regulations regarding device usage while riding a bicycle or driving a car, motorcycle, or other vehicle


Never use your device while driving, if it is prohibited by law. For your safety and the safety of others, use your common sense and remember the following tips:

- Suspend calls in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice, and heavy traffic can be hazardous.
- Dial sensibly and assess the traffic. Place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary.
- Do not engage in stressful or emotional conversations that may be distracting. Make the person you are talking to aware that you are driving and suspend conversations that could potentially divert your attention from the road.
- Position your device within easy reach. Make sure you can access your device without taking your eyes off the road.
- Do not record notes. Doing so may take attention away from your primary responsibility of driving safely.
- Be aware of your surroundings and traffic before using AI features. Using AI features while driving may distract your attention and cause an accident.

Do not use the device in dull light conditions or while driving at night

If the device lenses fall within Filter Category 1 through Category 3, use of the device may pose a risk.

Table 1 - Description of filter categories and assigned symbols

Filter category	Description	Usage	Symbol
0	Light tint sunglasses	Very limited reduction of sunglare	
1		Limited protection against sunglare	
2	General purpose sunglasses	Good protection against sunglare	
3		High protection against sunglare	
4	Very dark special purpose sunglasses, very high sunglare reduction	Very high protection against extreme sunglare, at sea, over snowfields, on high mountains, in desert, or other environments	
		Not suitable for driving and road use	

This device complies with ISO 12312-1:2022 and US FDA Reg.21 CFR 801.410 specifications.

Care and use your device properly

Keep your device dry

- Humidity and liquids may damage the parts or electronic circuits in your device.
- Do not turn on your device if it is wet. If your device is already on, turn it off (if the device will not turn off leave it as-is). Then, dry the device with a towel and take it to the official distributor.
- This device has internal liquid indicators fitted. Water damage to your device may void the manufacturer's warranty.

Store your device only on flat surfaces

If your device falls, it may be damaged.

The device can be used in locations with an ambient temperature of 0 °C to 35 °C. You can store the device at an ambient temperature of -10 °C to 45 °C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan

- Do not store your device in very hot areas such as inside a car in the summertime. Doing so may cause the device to malfunction, result in damage to the device, or cause the battery to explode.
- Do not expose your device to direct sunlight for extended periods of time (on the dashboard of a car, for example).

Do not store your device with metal objects, such as coins, keys, and necklaces

- Your device may be scratched or may malfunction.
- If the battery terminals come into contact with metal objects, this may cause a fire.

Do not store your device near magnetic fields

- Your device may malfunction or the battery may discharge from exposure to magnetic fields.
- Magnetic stripe cards, including credit cards, may be damaged by magnetic fields.

Avoid contact with your device when it is overheating. Failure to do so may cause low temperature burns, redness and skin pigmentation

- Do not use the device for extended periods. Be careful to not overheat the device during prolonged use.
- Do not sit on your device or make direct contact with your skin for extended periods when charging or connected to a power source.

- Tolerance to high temperature varies individually. Please take extra caution regarding the use of children, elders and people with special conditions.
- If your device has a flash, avoid exposing your skin to the flash when using it. Make sure that the flash is turned off after use.

Be careful not to expose the camera lens to a strong light source, such as direct sunlight or a laser

If the camera lens is exposed to a strong light source, such as direct sunlight, the camera image sensor may be damaged. A damaged image sensor is irreparable and will cause dots or spots in pictures.

If your device has a flash or light, do not use it close to the eyes of people or pets

Using a flash close to the eyes may cause temporary loss of vision or damage to the eyes.

Protect your hearing and ears when using your device



- Excessive exposure to loud sounds can cause hearing damage.
- Exposure to loud sounds while walking may distract your attention and cause an accident.
- Always turn the volume down before using the device and use only the minimum volume setting necessary to hear your conversation or music.

Read and follow the instructions regarding adverse symptoms provided with the device

- You may get an infection if the device comes into contact with foreign materials and you wear it for a long time. Keep your device clean and dry.
- If the symptoms of skin irritation continue, stop using the device and consult a physician.
- If you feel discomfort such as headaches, nausea, or other unusual symptoms while wearing the device for an extended period, stop using the device. If you continue to have discomfort, stop using the device and consult a physician.
- Make sure to consult a physician before using the device if you are pregnant, elderly, have psychiatric disorders or experience discomfort because of differences in vision between your eyes, or suffer from a heart condition or other serious medical condition.
- If the device has prescription lenses, use the device only by the user who requires vision correction. Use of the device with prescription lenses by other users may result in inadequate vision correction or worsened vision.

Use caution when using the device while walking or moving

Always be aware of your surroundings to avoid injury to yourself or others.

Do not paint or put stickers on your device

- Paint and stickers can clog moving parts and prevent proper operation.
- If you are allergic to paint or metal parts of the device, you may experience itching, eczema, or swelling of the skin. When this happens, stop using the device and consult your physician.

Use your device and equipment with caution

Avoid placing your device and accessories near or in an airbag deployment area. The device may be damaged or cause injury when airbags inflate rapidly.

Do not drop your device or cause impacts to your device

- Your device may be damaged or may malfunction.
- If bent or deformed, your device may be damaged or parts may malfunction.

Ensure maximum battery and charger life

- Batteries may malfunction if they are not used for 3 to 6 months.
- Over time, unused device will discharge and must be recharged before use.
- Disconnect the charger from power sources when not in use.
- Use the battery only for their intended purposes.
- Follow all instructions in this manual to ensure the longest lifespan of your device and battery. Damages or poor performance caused by failure to follow warnings and instructions can void your manufacturer's warranty.
- Your device may wear out over time. Some parts and repairs are covered by the warranty within the validity period, but damages or deterioration caused by using unapproved accessories are not.

Do not disassemble, modify, or repair your device

- Any unauthorized modification, alteration, or other tampering that prevents the outer indicator light from operating normally during camera recording is strictly prohibited.
- Any changes or modifications to your device can void your manufacturer's warranty. If your device needs servicing, take your device to the official distributor.
- Do not disassemble or puncture the battery, as this can cause explosion or fire.
- Do not disassemble or reuse the battery.

When cleaning your device, mind the following

- When cleaning the device, wipe it gently with the supplied cleaning cloth. Using dirty or abrasive cloths, or applying excessive force may deform the frame or lenses, or damage the surface.
- Do not use solvents, such as alcohol or ethanol, or perform ultrasonic cleaning.
- Do not spray water or other liquids directly onto the device or use them to clean the device.
- Do not clean the device while it is charging.
- Clean the charging contacts of the device with a cotton swab or a soft cloth.
- Do not use chemicals or detergents. Doing so may discolour or corrode the outside the device or may result in electric shock or fire.
- Prevent the device from being exposed to dust, sweat, ink, oil, and chemical products such as cosmetics, antibacterial spray, hand cleaner, detergent, and insecticides. The device's exterior and interior parts may be damaged or it could result in poor performance. If your device is exposed to any of the previously mentioned substances, use a lint-free, soft cloth to clean it.

Do not use the device to protect your eyes from mechanical impact or for any purpose other than its intended use

Your device is not protective equipment, such as industrial or sports protective eyewear. Using the device as protective equipment may increase the risk of eye or facial injury and cause the device to malfunction.

Do not look directly at the sun while wearing the device or use the device to protect your eyes from artificial light sources

Avoid disturbing others when using the device in public

Allow only qualified personnel to repair your device

Allowing unqualified personnel to repair your device may result in damage to your device and will void your distributor's warranty.

Handle cables with care

- When connecting a cable to your device, make sure that the cable is connected to the proper side.
- Connecting a cable by force or improperly may result in damage to the multipurpose jack or other parts of the device.

Protect your personal data and prevent leakage or misuse of sensitive information

- While using your device, be sure to back up important data. The distributor or manufacturer is not responsible for the loss of any data.
- When disposing of your device, back up all data and then reset your device to prevent misuse of your personal information.
- Follow all applicable local laws, rules, and regulations when using the device. Respect the rights, privacy, and confidentiality of others.
- Using the device to record while the outer indicator light is blocked or disabled may infringe on the rights of others. The distributor or manufacturer is not responsible for any issues arising from this.

Do not distribute copyright-protected material

Do not distribute copyright-protected material without the permission of the content owners. Doing this may violate copyright laws. The distributor or manufacturer is not liable for any legal issues caused by the user's illegal use of copyrighted material.

To reduce the risk of injury or discomfort, you should always follow these instructions and observe these precautions while using the device

- Always be aware of your surroundings before beginning use and while using the device. Use caution to avoid injury.
- Using the device with any accessories on your face may increase the risk of injury. Remove all accessories, such as nose rings or eyebrow piercings, before using the device to reduce the risk of injury. Also, do not use the device if your face is injured in any way.
- Listening to sound at high volumes can cause irreparable damage to your hearing. Background noise, as well as continued exposure to high volume levels, can make sounds seem quieter than they actually are. Do not use the device with the sound at a high volume so that you can maintain awareness of your surroundings and reduce the risk of hearing damage.